



IMPORTANT INFORMATION

- * THE BBQ GRILL SHOULD ALWAYS BE PLACED ON A STABLE SURFACE.
- * DO NOT MOVE THE GRILL WHEN HOT.
- * DO NOT SPRAY LIGHTER FLUID ON THE GRILL WHEN HOT
- * KEEP OUT OF THE REACH OF CHILDREN.
- * THIS GRILL IS FOR OUTDOOR USE ONLY.

ASSEMBLY INSTRUCTIONS.

- * ASSEMBLE THE HANDLE BRACKETS TO THE GRILL COVER (3) USING #B M5x8 BOLT AND NUT.
- * ASSEMBLE THE GRILL LEGS (5) TO THE BODY OF THE GRILL (4) USING #A M5X30 BOLT AND NUT.

LIGHTNING INSTRUCTIONS.

- * PLACE A LAYER OF CHARCOAL ON THE CHARCLAL GRATES, FOR QUICKER FIRE USE LIGHTER CUBES OR LIGHTER FLUID, THE USE AGRILL LIGHTER OR LONG STEM MATCH TO LIGHT THE GRILL, WHEN THE COALS REACH A GRAY COLOR, THEY ARE RBAUY FOR COOKING, ADD CHARCOAL TO THE FIRE AS NEEDED
- * ALLOW THE GRILL TO COOL BEFORE EXTINGUISHING THE FIRE.
- * PLEASE NAKE SURE THAT THE COALS ARE EXTINGUSHED COMPLETELY.
- * DO NOT LEAVE HOT COALS ON THE GROUND OR EXPOSED TO OTHER CONBUSTIBLE NATERIALS.

PARTS LIST

- #1 COOKING GRILL
- #2 CHARCOAL GRILL
- #3 COVER
- #4 BODY
- #5 LEG
- #6 HANDLE
- #7 WIRE HOOK
- #A BOLT (M5X30)
- #B BOLT (M5X8)
- #C NUT (M5)

QUANTITY

- 2PCS
- 2PCS
- 1PC
- 1PC
- 2PCS
- 1PC
- 1PC
- 6PCS
- 2PCS
- 8PCS